
Installation/Application



Installation/Application Instructions

For best results, apply this product on roofing membranes that have cured for 60 days or longer.

Use a brush, roller or spray equipment to apply JM CR Seam Coating. All surfaces must be clean, dry and free of any dirt, grease, oil or other debris that may interfere with proper adhesion. If multiple applications are needed, the first coat should be completely dry (normally 4 to 12 hours) before applying the subsequent coats.

Temperatures must be 50°F (10°C) and rising during time of application. Do not apply JM CR Seam Coating within 24 hours of anticipated rain, dew or freezing temperatures. As with any coating, cooler temperatures and high humidity will slow the cure time. Coating should be applied under normal environmental conditions without thinning. All equipment can be cleaned with water and heavy duty detergent.

Precautions

